

#### Installation

## 3 Resistor Wiring

Relay Status

		NOTHIAL LIK	Alaimi i iit	auit fairipe		
ı	Alarm Relay Clos	e Open Ope	n Close			
	Tamper Relay	Close	Close Close		Open	
	Method 1: Use	the jumper	to select E	OL (End of	Line) resista	nc

nce on TAMPER/ALARM EOL pins.

Method 2: Add the resistor to TAMPER/ALARM wiring ports.

Note: If EOL wiring is not used, leave the jumpers OFF. Do not force th jumper if it is not matched the pin. Method 1 & 2 should not be used ALARM/TAMPER at the same time.

a. Alarm Resistance: 1K, 2K2, 4K7, 5K6, 6K8

b. Tamper Resistance: 1K, 2K2, 4K7, 5K6

## 4 Connection Type

Note: The resistor must be connected in series with one end of the detector

- a. Normally Closed
- b. Single End of Line Wiring
- c. Double End of Line Wiring

# 5 Detection Range

## 6 Powering On

After powering on, the indicator flashes rapidly. Once the detector self test is completed, the LED indicator will go out until the detector detects movement.

#### Specification

Detection method	Passive Infrared		
Detection range 12 m			
Detection Angle 360°			
Detection zones 172			
Detectable speed 0.3~2 m/	4		
Sensitivity Auto, low			
White light filter 6500lux			
Digital temperature compensation	Support		
Creep zone protection Support	1		
Digital processing Support			
Sealed optics Support			
Tamper protection Front			
LED indicator Blue (Alarn	1)		
Power supply 9 to 16 VI	С		
Typical voltage 12 VDC			
Operation temperature -10 °C	to 55 °C (14 °F to 131 °F)		
Storage temperature -20 °C	to 60 °C (-4 °F to 140 °F)		
Operation humidity 10% to	90%		
Dimension $\phi$ 101.2 mm	32.9 mm		
Weight 109.5 g			
Mounting height 2.4 to 4	ή		
Mounting method Ceiling			
Application scenario Indoor			
Power Consumption 13mA N	ax		

Please use the power supplies comply with the requirements of EN 50131 6 at the appropriate grade and environmental class.

Please do not obscure the detector's field of view partially or completely.

UD23903B-E


3

TAMPER

1K 🕡 🖸

TAMPER

ALARM





4m 4m